

Iridium 9505a Voice Mail Set-up Instructions

Programming the Voicemail number into the “Envelope” option of the handset.

1. Press the [Envelope] key, “Call Voicemail, select?” will appear.
2. Scroll with the up/down arrows keys until “Message settings, view options?” appears.
3. Press [OK], “Voicemail number, select?” will appear.
4. Press [OK], enter the Iridium general voicemail number, **00881662990000**.
5. Press [OK], a check mark with the word “completed” will appear.
6. Hold on to the [C] (clear) key to return to the default screen, “Iridium”, continue to activating “Call Forwarding Unavailable”

Activating “Call Forwarding Unavailable” to voicemail.

**Phone must be powered ON, registered, and have strong signal strength (at least 2 to 3 bars)*

1. Press the [Menu] key, scroll with the up/down arrow keys until “Call Related Features” appears.
2. Press [OK], scroll down until “Call Forwarding” appears.
3. Press [OK], scroll down until “Forward When Unavailable” appears.
4. Press [OK], “Please Wait” will then appear, wait for a while until “On” appears.
5. Press [OK], scroll down until “Voicemail” appears.
6. Press [OK], “Please Wait” will then appear, wait for a few seconds until “Call Forward On” appears.
7. “Forward When Unavailable” then appears, hold on to the [C] button to return to the default screen.

Accessing your Personal Mailbox.

When the Iridium general VM number, **881662990000**, appears on your phone or pager, that means you’ve received a new voice message. ***By default, your password is the last 7 digits of your Iridium phone number. ***

Dialing the Iridium general voicemail number using the Envelope key on your Iridium handset.

1. Phone has to be powered ON, *registered, and have strong signal strength (at least 2 to 3 bars)*
2. Press the [Envelope] key, “Call Voicemail, select” will appear.
3. Press [OK], this will automatically call the Iridium general voicemail number, **8816-629-90000**.
4. Wait for the Iridium voice prompt asking you to “re-enter the Iridium phone number you are trying reach”.
5. Enter your Iridium phone number; you will then be forwarded to your personal voicemail greeting.
6. Press the [*] key to interrupt the greeting, and then enter your password to access your personal mailbox.
7. Follow the voice prompts for menu options.

Dialing your Iridium phone number using your Iridium handset.

1. Phone has to be powered ON, *registered, and have strong signal strength (at least 2 to 3 bars)*
2. Dial your phone number and wait for your personal voicemail greeting. **(00-8816-314-xxxxx)**
3. Press the [*] key to interrupt the greeting, and then enter your password to access your mailbox.
4. Follow the voice prompts for menu options.

Dialing your Iridium phone number using a landline (PSTN) phone.

1. Dial your phone number and wait for your personal voicemail greeting. Calls from a landline phone are international long distance calls, so you need to dial **011** before your phone number
2. **Example** :(011-8816-XXXX-XXXX).
3. Press the [*] key to interrupt the greeting, and then enter your password to access your mailbox.
4. Follow the voice prompts for menu options.

For all Iridium Satellite phone support documents, you can visit us at www.northernaccess.com or send us an email to support@northernaccess.com to request forms